INSTALLATION MANUAL

Level of Difficulty

Easy

Installation difficulty levels are based on time and effort involved and may vary depending on the installer level of expertise, condition of the vehicle and proper tools and equipment.

Parts List

Qty	Description
1	Driver / left running board
1	Passenger / right running board
18	Flange nut, M8

Tools Required


Socket, 12mm	--

Torque Specifications

M8 bolt	20 ft-lbs.

Use above torque setting unless otherwise noted

Product Photo



Product Photo



NOTICE

Visit **www.ranchhand.com** for a full-color copy of this instruction manual, as well as helpful videos, guides and much more!

Before you begin installation, read all instructions thoroughly.

Proper tools will improve the quality of installation and reduce the time required.

Periodic inspection of your product should be performed to ensure all hardware and / or components remain secure.

To help prevent damage to the product or vehicle, refer to the specified torque specifications when securing hardware during the installation process.

Maintenance

Mild automotive detergent may be used to clean the product. Do not use dish detergent, abrasive cleaners, abrasive pads, wire brushes or other similar products that may damage the finish.

Product Registration and Warranty

Ranch Hand stands behind our products with industry-leading warranties. To get copies of the product warranties, register your purchase or provide feedback, visit: **warranty.curtgroup.com/surveys**

Step 1

Starting on the driver side, remove all M8 flange nuts from the M8 factory-threaded studs to remove the OE running boards.

Repeat on the passenger side of the vehicle.



Step 2

Locate the driver-side running step. The larger step will go towards the front of the vehicle and the straight-capped end will go towards the rear of the vehicle.

Step 3

Carefully raise the running step into position and align the three brackets with the nine M8 OE threaded studs.

Step 4

Using the supplied M8 flange nuts, loosely secure the running step to the vehicle in the nine mounting positions.



Step 5

Starting with the rear bracket, push up towards the pinch weld so that the 3" main bar is as high and tight to the body as possible.

Tighten all three M8 flange nuts to the recommended torque specifications listed on page 1.

Step 6

Move to the front bracket and repeat step 5. Finish by securing the center bracket

Step 7

Repeat steps 3 through 6 on the passenger side of the vehicle.

To protect your investment, see the 'Notes and Maintenance' section on page one.

Congratulations on the installation of your new Ranch Hand™ running steps.